

Model:	Artera Play+
Version:	V1.11
Issue date:	May 2021
Type:	Public

Improvement:

- Minor operational improvements

Additional information

Firmware update instructions.

1. Turn off the power supply to the device (rear panel mains switch)
2. Copy the 'Artera.bin' file to the root of a FAT32 formatted USB drive (maximum 32GB).
3. Insert the USB drive to the 'UPDATE' USB socket on the rear panel of the device.
4. Push and hold front panel standby button.
5. Turn on the power supply to the device (rear panel mains switch) while continuing to hold the standby button.
6. Release the standby button and the display will show 'Finished' when updated. You can ignore any messages prior to this
8. When the update is complete, the device will go into standby. Switch it back on and it is now ready to use.